

<b>Elementis Specialties, Inc.</b>	<b>Elementis GmbH</b>
P.O. Box 700, Wyckoffs Mill Rd.	Technical Centre
Hightstown, NJ 08520	Stolberger Strasse 370
Tel.: +1-609-443 2500	50933 Cologne, Germany
Fax: +1-609-443 2422	Tel: +49 (0)221 2923 2000
specialinfo.usa@elementis-na.com	Fax: +49 (0)221 2923 2010
Web: www.elementis-specialties.com	specialinfo.eu@elementis-eu.com



# ANTIPERSPIRANT STICK

## 57-3H

Antiperspirant Stick containing FANCOL<sup>®</sup> POLYISO<sup>®</sup> 250-CG and THIXCIN<sup>®</sup> R.

### Advantages

The presence of FANCOL<sup>®</sup> POLYISO<sup>®</sup> 250-CG and THIXCIN<sup>®</sup> R in this system:

- Improve waterproofing
- Give structure to the stick
- Provide a nice feel

Ingredient	Supplier	% w/w
<b>PHASE A</b>		
Cyclopentasiloxane		51.0
Tego Alkanol 18 (Stearyl Alcohol)	Evonik	16.5
<b>PHASE B</b>		
<b>THIXCIN<sup>®</sup> R (Trihydroxystearin)</b>	<b>ELEMENTIS Specialties</b>	<b>2.5</b>
<b>PHASE C</b>		
<b>FANCOL<sup>®</sup> POLYISO<sup>®</sup> 250-CG (Hydrogenated Polyisobutene)</b>	<b>ELEMENTIS Specialties</b>	<b>5.0</b>
Reach AZP-908 Super Ultrafine (Aluminium Zirconium Tetrachlorohydrate Glycerine)	Reheis	25.0

---

## Method of Manufacture

1. Put Phase A into a container and heat to 80°C.
2. Add Phase B and mix thoroughly.
3. Cool to 75°C and add Phase C. Mix.
4. Cool to 70°C and fill.

N.B.

Please refer to the Product Data Sheets for additional advice on incorporation.

---

The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchases will be subject to a separate agreement which will not incorporate this document.