

# Cheek Rouge

TS-129

ELEMENTIS

SPECIALTIES

## Description

This creamy rouge blush applies easily to the cheeks leaving a silky smooth glow.

## Advantages

The presence of BENTONE GEL® NIO V and THIXCIN® R in this system:

- Provide thixotropic flow properties to improve ease of application and deliver coverage evenly with a natural look
- Improve the suspension of the pigments
- Enhance the stability of the formulation, by providing thermostability, electrolyte tolerance and viscosity

The presence of FANCOR® Lanolin in this system:

- Provides lipid rich emolliency
- Provides excellent moisturization benefits
- Softens the skin

Phase	Ingredient	Supplier	%w/w
A	Lanolin	ELEMENTIS	10.00
	FANCOR® Lanolin, USP Cosmetic	Specialties	
	Trihydroxystearin	ELEMENTIS	2.50
	THIXCIN® R	Specialties	
	Mineral Oil (Blandol)	Sonneborn	17.00
	Ethylhexyl Palmitate		15.00
B	Beeswax		6.00
	Propylparaben		0.15
	Mineral Oil (and) Disteardimonium Hectorite (and) Propylene Carbonate	ELEMENTIS	15.00
	BENTONE GEL® MIO V	Specialties	
	Ricinus Communis (Castor) Seed Oil (and) Red 7 Lake (COD 8001)	Sun Chemical	15.00
	Mica (and) Titanium Dioxide (Timiron MP-30)	EMD	4.00
D	Talc		18.00
	Titanium Dioxide		6.00

## Procedure:

1. Heat Phase A to 85°C.
2. Cool to 80°C. Add Phase B to Phase A using a Silverson homogenizer at medium speed. Mix for 10 minutes at 80°C.
3. Add Phase C and mix for 5 minutes.
4. Add Phase D to batch and mix for 5 minutes.
5. Continue mixing at medium speed until homogenous.
6. Remove from heat and hot pour into mold or container.

The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchases will be subject to a separate agreement which will not incorporate this document.

For more details please contact:

AMERICAS ELEMENTIS Specialties  
469 Old Trenton Road  
East Windsor, NJ 08512  
USA  
Tel: +1.609.443.2000  
Fax: +1.609.443.2422

EUROPE ELEMENTIS Specialties  
Stolberger Strasse 370  
50933 Cologne  
Germany  
Tel: +49.221.2923.2000  
Fax: +49.221.2923.2010