

Elementis Specialties, Inc.
P.O. Box 700, Wyckoffs Mill Rd.
Hightstown, NJ 08520
Tel.: +1-609-443 2500
Fax: +1-609-443 2422
specialinfo.usa@elementis-na.com
Web: www.elementis-specialties.com

Elementis Specialties
PEGASUSPARK
De Kleetlaan 12 a, bus 3
1831 Diegem, Belgium
Tel.: +32-2-790 76 00
Fax: +32-2-790 76 60
specialinfo.eu@elementis-eu.com



FACE MASK WITH BENTONE® EW

SACI-CFPA

Face Mask containing BENTONE® EW, rheological additive

Advantages

The presence of BENTONE® EW, rheological additive in this system:

- Provides viscosity and stability to the formulation

Ingredient	Supplier	% w/w
PHASE A		
BENTONE® EW (Hectorite)	ELEMENTIS Specialties	5.0
Spherica P1500 (Silca)	Ikeda	3.0
Spherititan AA 15-14 (Titanium Dioxide)	Ikeda	1.0
Silkall TL (Talc and Silk)	Ikeda	1.0
PHASE B		
Deionised Water		90.0

Method of Manufacture

1. Blend Phase A together.
2. Add Phase A to Phase B with mixing.

N.B.

Please refer to the Product Data Sheets for additional advice on incorporation.

The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchases will be subject to a separate agreement which will not incorporate this document.