

**Elementis Specialties, Inc.**  
P.O. Box 700, Wyckoffs Mill Rd.  
Hightstown, NJ 08520  
Tel.: +1-609-443 2500  
Fax: +1-609-443 2422  
specialinfo.usa@elementis-na.com  
Web: www.elementis-specialties.com

**Elementis Specialties**  
PEGASUSPARK  
De Kleetlaan 12 a, bus 3  
1831 Diegem, Belgium  
Tel.: +32-2-790 76 00  
Fax: +32-2-790 76 60  
specialinfo.eu@elementis-eu.com

**ELEMENTIS**  
SPECIALTIES

## HAND CREAM WITH BENTONE® EW

### SACI-CFPA 691/10/03

Hand Cream containing BENTONE® EW, rheological additive.

#### Advantages

The presence of BENTONE® EW, rheological additive in this system:

- Gives body to the product
- Provides thermostability and improves emulsion stability

Ingredient	Supplier	% w/w
<b>PHASE A</b>		
BENTONE® EW (Hectorite)	ELEMENTIS Specialties	1.0
Deionised Water		79.8
<b>PHASE B</b>		
Dermol 489 (Diethylene Glycol Dioctanoate/ Diisonnoate)	Alzo International	8.0
Lasemul 92 N 40 (Glycerol Monostearate)	Lasem	5.0
<b>PHASE C</b>		
Ethanol		5.0
Spherica P 1500 (Silica)	Ikeda	1.0
Paratexin FPX (Phenoxyethanol and Methylparaben and Ethylparaben and Propylparaben and Butylparaben and Isobutylparaben)	S. Black Group	0.2

---

## Method of Manufacture

1. Disperse Phase A and heat to 70°C.
2. Heat Phase B to 75°C and add to Phase A with silverson homogenising.
3. Commence cooling with stirring till 35°C.
4. Add Phase C to Phase A+ B and mix.

N.B.

Please refer to the Product Data Sheets for additional advice on incorporation.

---

The information herein is currently believed to be accurate. We do not guarantee its accuracy. Purchasers shall not rely on statements herein when purchasing any products. Purchasers should make their own investigations to determine if such products are suitable for a particular use. The products discussed are sold without warranty, express or implied, including a warranty of merchantability and fitness for use. Purchases will be subject to a separate agreement which will not incorporate this document.