

Hair & Scalp Boosting Serum 14817-70

Description

This moisturizing serum gives new life to dry hair and scalp by infusing it with a boost of moisture. Hydrovance provides moisture to hair and scalp an hair strengthening. Elfamoist AC further improves the moisturization of the scalp. Amaze XT and Celquat L-200 makes the hair smooth and easy to sculpt while wet. When the hair is dry, they help fixating the hairstyle.

Formula

Trade Name	INCI Name	%w/w	Supplier
Phase A			
Deionized Water	Aqua (Water)	35.000	Local
Celquat® L-200 polymer	Polyquaternium-4	0.200	Nouryon
Phase B			
Deionized Water	Aqua (Water)	54.839	Local
Dissolvine® GL-47-S	Tetrasodium Glutamate Diacetate	0.200	Nouryon
Citric Acid 25%	Citric Acid (and) Water	0.950	Local
Amaze® XT polymer	Dehydroxanthan Gum	0.900	Nouryon
Phase C			
ElfaMoist® AC humectant	Acetamidoethoxyethanol	2.000	Nouryon
HYDROVANCE® moisturizing agent (50% Hydroxyethyl Urea active)		5.000	Nouryon
Citroflex® 2	Triethyl Citrate	0.500	Vertellus Performance Materials Inc.
Microcare NB	Sodium Benzoate	0.270	Thor
Microcare KS	Potassium Sorbate	0.140	Thor
Citric Acid 25%	Citric Acid (and) Water	0.001	Local
Total:		100.000	

Procedure

Phase A Start propeller mixing of the deionized water. Slowly pour Celquat L-200 into the vortex and continue mixing until a homogenous transparent gel is formed. Phase B Dissolve Dissolvine GL-47-S into the deionized water. Adjust ph to 4.0-4.5 with the citric acid. Start mixing with anchor stirrer or simililar. Pour Amaze XT into the vortex of the liquid and continue mixing until a homogenous gel is formed. Add slowly phase A into phase B while mixing. Phase C Premix Elfamoist AC, Hydrovance and Citroflex-2 and add it into the main vessel. Add Microcare NB. When Microcare NB is dissolved, add Microcare KS. Continue mixing until a clear homomogenous gel is formed. Adjust pH to 4.0-4.5 if needed.

Properties

pH 4 - 4.5

Created:2023-06-27 07:06:30 GMT **Modified:**2025-07-11 08:07:48 GMT

Europe:Stenungsund, Sweden, T: +46 303 85000, F: +46 303 771973, e: personalcare.europe@nouryon.com

Americas:Chicago, Illinois, US, T: +1 800 906-9977, F: +1 908-707-3664, e: personalcare.usa@nouryon.com

South America:Itupeva, SP, Brazil, T: +55-11-4591-8870, F: +55-11-4591-8804, e: personalcare.southamerica@nouryon.com

Asia/Pacific:Shanghai, P.R., China, T: +86-21-2220-5000, F: +86-21-2220-5558, e: personalcare.china@nouryon.com

Hair & Scalp Boosting Serum**14817-70****Packaging**

All information concerning our products and/or all suggestions for handling and use contained herein (including formulation and toxicity information) are offered in good faith and are believed to be reliable. However Nouryon makes no warranty express or implied (i) as to the accuracy or sufficiency of such information and/or suggestions, (ii) as to any product's merchantability or fitness for a particular use or (iii) that any suggested use (including use in any formulation) will not infringe any patent. Nothing contained herein shall be construed as granting or extending any license under any patent. The user must determine for itself by preliminary tests or otherwise the suitability of any product and of any information contained herein (including but not limited to formulation and toxicity information) for the user's purpose. The safety of any formulations described herein has not been established. The suitability and safety of a formulation should be confirmed in all respects by the user prior to use. The information contained herein supersedes all previously issued bulletins on the subject matter covered.

Created:2023-06-27 07:06:30 GMT **Modified:**2025-07-11 08:07:48 GMT

Europe:Stenungsund, Sweden, T: +46 303 85000, F: +46 303 771973, e: personalcare.europe@nouryon.com

Americas:Chicago, Illinois, US, T: +1 800 906-9977, F: +1 908-707-3664, e: personalcare.usa@nouryon.com

South America:Itupeva, SP, Brazil, T: +55-11-4591-8870, F: +55-11-4591-8804, e: personalcare.southamerica@nouryon.com

Asia/Pacific:Shanghai, P.R., China, T: +86-21-2220-5000, F: +86-21-2220-5558, e: personalcare.china@nouryon.com